

## **CHANGING BATTERIES**

The CTP-3 is powered by 4 AA alkaline batteries located in the tuner/battery cartridge.

To replace the batteries, pinch the two cartridge tabs and pull out the cartridge. Replace the batteries carefully observing polarity.





## CONTROL

